

PDXXX Series RS-232 Codes

Baud Rate: 115200

Data Bits: 8

Parity: NONE

Stop Bits: 1

Item	Comment	Code	ASCII Code
1	Power On/Off	0x07 0x00 0x01 0x50 0x4F 0x4E 0x08	PON
2	Power off	0x07 0x00 0x01 0x50 0x4F 0x46 0x08	POF
3	Menu Zoom on / off	0x07 0x00 0x01 0x4D 0x45 0x5A 0x08	MEZ
4	Volume	0x07 0x00 0x01 0x56 0x4F 0x4C 0x08	RIG
5	Volume +	0x07 0x00 0x01 0x4C 0x45 0x46 0x08	LEF
6	Volume -	0x07 0x00 0x01 0x4D 0x55 0x54 0x08	MUT
7	Audio Mute On / Off	0x07 0x00 0x01 0x43 0x4F 0x4E 0x08	CON
8	Contrast	0x07 0x00 0x01 0x42 0x52 0x49 0x08	BRI
9	Brightness	0x07 0x00 0x01 0x53 0x48 0x41 0x08	SHA
10	Sharpness	0x07 0x00 0x01 0x53 0x41 0x54 0x08	SAT
11	Saturation	0x07 0x00 0x01 0x48 0x55 0x45 0x08	HUE
12	Hue	0x07 0x00 0x01 0x49 0x52 0x45 0x08	IRE
13	Image Settings Reset	0x07 0x00 0x01 0x41 0x53 0x50 0x08	ASP
14	Aspect Ratio	0x07 0x00 0x01 0x46 0x55 0x4C 0x08	FUL
15	Aspect Ratio 4:3	0x07 0x00 0x01 0x4C 0x45 0x54 0x08	LET
16	Aspect Ratio 16:9	0x07 0x00 0x01 0x4F 0x4E 0x45 0x08	ONE
17	Aspect Ratio Letterbox	0x07 0x00 0x01 0x56 0x47 0x41 0x08	VGA
18	Aspect Ratio Native	0x07 0x00 0x01 0x48 0x44 0x4D 0x08	HDM
19	main input	0x07 0x00 0x01 0x48 0x44 0x4E 0x08	HDN
20	PC Input	0x07 0x00 0x01 0x4E 0x45 0x4E 0x08	NEN
21	HDMI 1 Input	0x07 0x00 0x01 0x4E 0x45 0x4D 0x08	NEM
22	HDMI 2 Input	0x07 0x00 0x01 0x53 0x49 0x54 0x08	SIT
23	Componenet Video 1	0x07 0x00 0x01 0x53 0x49 0x55 0x08	SIU
24	Componenet Video 2	0x07 0x00 0x01 0x53 0x56 0x49 0x08	SVI
25	Composite Video 1	0x07 0x00 0x01 0x50 0x47 0x41 0x08	PGA
26	Composite Video 2	0x07 0x00 0x01 0x50 0x44 0x4D 0x08	PDM
27	S-Video	0x07 0x00 0x01 0x50 0x44 0x4E 0x08	PDN
28	PIP Source Select- PC	0x07 0x00 0x01 0x50 0x45 0x4E 0x08	PEN
29	PIP Source Select- HDMI 1	0x07 0x00 0x01 0x50 0x45 0x4D 0x08	PEM
30	PIP Source Select- HDMI 2	0x07 0x00 0x01 0x50 0x49 0x54 0x08	PIT
31	PIP Source Select- Component 1	0x07 0x00 0x01 0x50 0x49 0x55 0x08	PIU
32	PIP Source Select- Component 2	0x07 0x00 0x01 0x50 0x56 0x49 0x08	PVI
33	PIP Source Select- Composite 1	0x07 0x00 0x01 0x50 0x49 0x50 0x08	PIP
34	PIP Source Select- Composite 2	0x07 0x00 0x01 0x50 0x49 0x4C 0x08	PIL
35	PIP Source Select - S-Video	0x07 0x00 0x01 0x50 0x49 0x53 0x08	PIS
36	PIP Mode(Picture)	0x07 0x00 0x01 0x53 0x42 0x53 0x08	SBS
37	PIP Picture Off	0x07 0x00 0x01 0x50 0x42 0x52 0x08	PBR
38	PIP Picture Mode- Large	0x07 0x00 0x01 0x50 0x42 0x4C 0x08	PBL
39	PIP Picture Mode- Small	0x07 0x00 0x01 0x50 0x54 0x4C 0x08	PTL
40	PIP Picture Mode- Side-by-Side	0x07 0x00 0x01 0x50 0x54 0x52 0x08	PTR
41	PIP Position	0x07 0x00 0x01 0x53 0x57 0x41 0x08	SWA
42	PIP Swap	0x07 0x00 0x01 0x54 0x55 0x53 0x08	TUS
43	Status	0x07 0x00 0x01 0x5A 0x4F 0x55 0x08	ZOU
44	Digital Zoom + / -	0x07 0x00 0x01 0x5A 0x49 0x4E 0x08	ZIN
45	Zoom +	0x07 0x00 0x01 0x46 0x52 0x45 0x08	FRE
46	Zoom -	0x07 0x00 0x01 0x55 0x53 0x45 0x08	USE
47	Freeze On / Off	0x07 0x00 0x01 0x53 0x50 0x4F 0x08	SPO
	Freeze On/Off		
	Scheme "User"		
	Scheme "Sport"		

48		Scheme "Game"	0x07 0x00 0x01 0x47 0x41 0x4D 0x08	GAM
49		Scheme "Theater"	0x07 0x00 0x01 0x54 0x48 0x45 0x08	THE
50		Scheme "Vivid"	0x07 0x00 0x01 0x56 0x49 0x56 0x08	VIV
51	Menu "Exit"	Menu "Exit"	0x07 0x00 0x01 0x45 0x58 0x49 0x08	EXI
52	Menu "Enter"	Menu "Enter"	0x07 0x00 0x01 0x45 0x4E 0x54 0x08	ENT
53	Menu Arrow Key > (Right)	Menu Arrow Key > (Right)	0x07 0x00 0x01 0x52 0x49 0x47 0x08	RIG
54	Menu Arrow Key < (Left)	Menu Arrow Key < (Left)	0x07 0x00 0x01 0x4C 0x45 0x46 0x08	LEF
55	Menu Arrow Key v	Menu Arrow Key v	0x07 0x00 0x01 0x44 0x4F 0x57 0x08	DOW
56	Menu Arrow Key ^	Menu Arrow Key ^	0x07 0x00 0x01 0x55 0x50 0x44 0x08	UPD
57	Menu Key	Menu Key	0x07 0x00 0x01 0x4D 0x45 0x4E 0x08	MEN